

Fig. 1

General components of the Bordier Stinky Free  
(Air suction pump)

1. Toilet	12. Toilet Seat Cover
2. Pump	13. Hinge
3. Expulsion Duct Hose	14. Suction Duct
4. Suction Duct Hose	15. Expulsion Duct
5. Suction Orifice	16. Electric Plug
6. Gap	17. Switch
7. Air Chamber	18. Arrows Indicate Air Circulation
8. Air Chamber Orifice to drain Water	19. Electrical Cable Duct
9. Timer	20. Foot-stool
10. Adult Toilet Seat	21. Electric Cable
11. Children Toilet Seat	




Fig. 7




Fig. 9




Fig. 6




Fig. 8




Fig. 6




Fig. 7




Fig. 8




Fig. 9




Fig 10




Fig 11




Fig 12